

### **Technical Precautions for Design, Installation and Maintenance**

## 34) External Connection Diagrams for Standard Motorized Pulleys


# Standard Terminal Box 0.5 HP - 330 HP

Diagrams are valid for Motorized Pulleys manufactured after January 2011. For units built prior to this date contact Rulmeca or refer to Repair and Maintenance Guide available at www.rulmecacorp.com.

T1 & T2 = Internal bi-metallic thermal protection switch which *MUST BE CONNECTED* to external normally closed control circuit.

See Technical Precautions pages 78 - 88 for complete electrical design, installation, and maintenance instructions.

#### **USA standard 460V power supply**



### USA standard 230V power supply

